

FreeIPMI Frequently Asked Questions

Free Intelligent Platform Management System
Version 0.7.15 updated on 19 November 2009

by Albert Chu chu11@l1n1.gov

Copyright © 2003-2008 FreeIPMI Core Team

This manual is for FreeIPMI (version 0.7.15, 11 November 2009). Copyright © 2006-2008 FreeIPMI Core Team

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts.

Table of Contents

0.1	IPMI - Platform Management Standard	1
0.2	What is FreeIPMI?	1
0.3	How did it start?	1
0.4	Who maintains FreeIPMI?	1
0.5	What is the relationship between FreeIPMI, OpenIPMI, Ipmitool, and Ipmiutil?	1
0.6	What is special about FreeIPMI compared to other open source IPMI projects?	2
0.7	SSIF Driver Configuration	4
0.8	x86-64 Compilation	4
0.9	SUNBMC Driver Compilation	5
0.10	Installing FreeIPMI on FreeBSD	5

0.1 IPMI - Platform Management Standard

The IPMI specifications define standardized, abstracted interfaces to the platform management subsystem. IPMI includes the definition of interfaces for extending platform management between the board within the main chassis and between multiple chassis.

The term platform management is used to refer to the monitoring and control functions that are built in to the platform hardware and primarily used for the purpose of monitoring the health of the system hardware. This typically includes monitoring elements such as system temperatures, voltages, fans, power supplies, bus errors, system physical security, etc. It includes automatic and manually driven recovery capabilities such as local or remote system resets and power on/off operations. It includes the logging of abnormal or out-of-range conditions for later examination and alerting where the platform issues the alert without aid of run-time software. Lastly it includes inventory information that can help identify a failed hardware unit.

0.2 What is FreeIPMI?

FreeIPMI is a collection of Intelligent Platform Management IPMI system software. It provides in-band and out-of-band software and a development library conforming to the Intelligent Platform Management Interface (IPMI v1.5 and v2.0) standards.

0.3 How did it start?

In October 2003, California Digital Corp. (CDC) was contracted by Lawrence Livermore National Laboratory (LLNL) for the assembly of Thunder, a 1024 node Itanium2 cluster. This led to software developers from CDC and LLNL merging the IPMI software developed by both organizations into FreeIPMI.

Anand Babu, Balamurugan and Ian Zimmerman at CDC contributed the in-band KCS driver, ipmi-sensors, bmc-config, ipmi-sel, bmc-info, and portions of libfreeipmi. Albert Chu and Jim Garlick at LLNL contributed ipmipower, bmc-watchdog, ipmiping, rmccpping, portions of libfreeipmi, and ipmi support in Powerman. In October 2004, FreeIPMI 0.1.0 was officially released.

Since the 0.1.0 release, Z Research developers have contributed ipmi-chassis, ipmi-raw, ipmi-locate, and portions of pef-config. LLNL has contributed IPMI 2.0 support, hostrange support, ipmiconsole, ipmimonitoring, ipmidetect, ipmi-sensors-config, ipmi-chassis-config, bmc-device, ipmi-oem, and portions of pef-config.

(Note: The original FreeIPMI developers from California Digital Corp. are now at Zresearch Inc.)

0.4 Who maintains FreeIPMI?

Primary maintenance of FreeIPMI is currently managed by Lawrence Livermore National Laboratory (LLNL). Overall maintenance of FreeIPMI has been handled by staff at CDC, Zresearch, and LLNL during the lifetime of FreeIPMI.

0.5 What is the relationship between FreeIPMI, OpenIPMI, Ipmiutil, and Ipmiutil?

There are multiple implementations, APIs, interfaces, end user requirements, etc. that one can choose when developing IPMI drivers, libraries, and tools. FreeIPMI has taken some different approaches than other open-source projects.

0.6 What is special about FreeIPMI compared to other open source IPMI projects?

In our eyes, there are several reasons why FreeIPMI is particularly special.

1) Support for HPC

A number of HPC aspects have been added to the tools and/or are supported by other HPC software due to the need for FreeIPMI to work on LLNL's Linux clusters.

Ipmipower is capable of scaling to large nodes for cluster support. It is supported by Powerman (<http://sourceforge.net/projects/powerman>) for scalable power management. At LLNL, in conjunction with Powerman, ipmipower is used for power control on clusters ranging from sizes of 4 to 1152. It is capable of power controlling all of the nodes in the largest clusters in under a second.

Ipmiconsole is currently supported by Conman (<http://home.gna.org/conman/>) for scalable console management.

Scalable parallel execution of many FreeIPMI tools (i.e. ipmi-sensors, ipmi-sel, bmc-info, ipmimonitoring, etc.) across a cluster is supported through hostranged input and output. For example:

```
# > bmc-info -h "pwopr[0-5]" -u XXX -p XXX -C
-----
pwopr[0-1,5]
-----
Device ID:          22
Device Revision:    1
Firmware Revision: 1.12
                   [Device Available (normal operation)]
IPMI Version:       2.0
Additional Device Support:
                   [Sensor Device]
                   [SDR Repository Device]
                   [SEL Device]
                   [FRU Inventory Device]
                   [Chassis Device]
Manufacturer ID:    28C5h
Product ID:         4h
Aux Firmware Revision Info: 38420000h
Channel Information:
    Channel No: 1
    Medium Type: 802.3 LAN
    Protocol Type: IPMB-1.0
    Channel No: 5
```

```

                Medium Type: Asynch. Serial/Modem (RS-232)
                Protocol Type: IPMB-1.0
-----
pwopr[2-4]
-----
Device ID:          22
Device Revision:    1
Firmware Revision: 1.23
                   [Device Available (normal operation)]
IPMI Version:       2.0
Additional Device Support:
                   [Sensor Device]
                   [SDR Repository Device]
                   [SEL Device]
                   [FRU Inventory Device]
                   [Chassis Device]
Manufacturer ID:    28C5h
Product ID:         4h
Aux Firmware Revision Info: 38420000h
Channel Information:
    Channel No: 1
    Medium Type: 802.3 LAN
    Protocol Type: IPMB-1.0
    Channel No: 5
    Medium Type: Asynch. Serial/Modem (RS-232)
    Protocol Type: IPMB-1.0

```

In the above example, its clear to see that pwopr[2-4] have different firmware than pwopr[0-1,5]. More information about hostrange support can be found in the document freeipmi-hostrange.txt.

Ipmidetector can be used to enhance the efficiency of the hostranged input by eliminating those nodes in the cluster that have been temporarily removed for servicing.

Ipmimonitoring interprets sensor readings as well as just reporting them. It can be used for host monitoring IPMI on a cluster. By mapping sensor readings into NOMINAL, WARNING, or CRITICAL states, it makes monitoring sensors easier across large numbers of nodes. Skumme (<http://sourceforge.net/projects/skumme>) uses libipmimonitoring on LLNL clusters up to 1152 nodes in size. FreeIPMI monitoring plugins for Ganglia (<http://ganglia.info/>) and Nagios (<http://www.nagios.org/>) have also been developed and made available for download (<http://www.gnu.org/software/freeipmi/download.html>).

The bmc-config, pef-config, ipmi-sensors-config, and ipmi-chassis-config configuration file and command-line interface are used to easily copy the BMC configuration from one node to every other node in a cluster quickly. It has been used to modify the BMC configuration across large LLNL clusters in a few minutes. They also have the capability to verify (via the diff option) that the desired configuration has been properly stored to firmware.

2) Easy setup

By implementing drivers in userspace libraries, there is no need to build/setup/manage any kernel modules/drivers.

3) Portability

Likewise, by implementing everything in userspace libraries and tools, portability to multiple operating systems and architectures should be easier.

0.7 SSIF Driver Configuration

FreeIPMI's SSIF driver works on top of kernel's i2c device interface.

Under GNU/Linux load these kernel modules: i2c-dev, i2c-i801, i2c-core before using FreeIPMI.

To identify SSIF device address:

Example:

```
$> lspci (in the output look for this entry)
00:1f.3 SMBus: Intel Corp. 6300ESB SMBus Controller (rev 01)
  Subsystem: Intel Corp.: Unknown device 342f
  Flags: medium devsel, IRQ 17
  I/O ports at 0400 [size=32]
      ----
$> cat /proc/bus/i2c
i2c-0  smbus  SMBus I801 adapter at 0400          Non-I2C SMBus adapter
      ----
```

Make sure the "0400" above matches with the "0400" address under proc. Also make sure "i2c-0" is not different. If it appears different then grep for "i2c-0" in this code "ipmitool.c" and change. "i2c-X" is the label assigned to each slave device attached on the i2c bus.

BMC address Locator:

Refer to the SM BIOS IPMI Device Information Record Type 38, record 06h and 08h. Use the value of record 06h as the IPMBAddress and load the SMBus controller driver at the address value read from record 08h.

Usual values for record 06h -> 0x42
Usual values for record 08h -> 0x400

0.8 x86-64 Compilation

Under some x86-64 platforms such as SUSE GNU/Linux, native 64 bit libraries reside under lib64 and 32 bit libs under lib. Autotools by default installs libfreeipmi.so under /usr/lib, instead of /usr/lib64 causing dynamic linking errors. Pass libdir appropriately to configure script to workaround this problem. (i.e. --libdir=/usr/lib64)

Example:

```
# ./configure --prefix=/usr --libdir=/usr/lib64
```

0.9 SUNBMC Driver Compilation

In order to compile the sunbmc driver, the `bmc_intf.h` header file must be in your include path. This can be added by to the include search path by adding the path to the `CPPFLAGS` environment variable. i.e.

```
in bash
    export CPPFLAGS='-I/my/bmc_intf_path/'
in csh/tcsh
    setenv CPPFLAGS '-I/my/bmc_intf_path/'
```

If the file is not on your system, the `bmc_intf.h` file may simply be downloaded from (<http://opensolaris.org/>) and installed into any location.

0.10 Installing FreeIPMI on FreeBSD

You can install a binary package of `freeipmi` or use the port, located in `ports/sysutils/freeipmi`, to build it from the source. See `ports(7)` and 'Packages and Ports' section (http://www.freebsd.org/doc/en_US.ISO8859-1/books/handbook/ports.html) in The FreeBSD Handbook.

Please contact port maintainer (MAINTAINER line in the port's Makefile), if you have problems building from the port.